Materials

- Main Fabric, 9" x 5", pre-washed
- Lining Fabric, 9" x 5", pre-washed
- Insulated Batting, 9" x 5" (we used insul-Bright)
- Normal quilt batting, 9" x 5" (optional, we used it because we want our pot holder thicker and loftier)
- Ribbon Or Fabric Bias Tape, 4".
- PotHolder Sewing Pattern (included)

Instructions

1. Get ready all the materials listed above, including a printed potholder pattern.
   Stack the fabrics and batting in the following arrangement (from bottom to top):
   a - main fabric (facing up)
   b - lining fabric (facing down)
   c - optional quilting fabric
   d - insulated batting (shiny side down)
   Pin them together
   Place the paper template on the insulated batting and trace the outline with a pen or marker.

If you are making your own fabric loop, cut a piece of 1 ½ x 4" fabric in biased grain. Use the bias tape maker and iron to fold ¼" of fabric from the edge lengthwise.
Then, fold the biased tape to ¼" and sew near the edge along the lengthwise of the biased tape.

Return to the fabric pile we just stacked; sew the half-moon curve with a ¼" seam allowance.
Use a pinking shear to cut along the trace lines and remove the excess fabrics. If you are using ordinary scissors, snip a few cuts at the seam allowance to ensure the seam is smooth when it is turned right-side out.

Attach the hanging loop to the middle of the main fabric with the following steps:
- fold the biased tape or ribbon in half.
- align and place the loop ends on the seam allowance at the middle of the main fabric (right side), with the ends aligned to the raw edges and the fold heading inside.
- stitch the ends on the seam allowance to secure their positions.
- if you have a label, you may sew it on similarly.

With the batting side facing up, grab the batting layer (or layers if you included a normal batting layer, as we did) and fold it over to the bottom of the pile.
The lining fabric is now on the top of the pile, with the wrong side facing up.

Bring the seam corners (A) together and align them in the cavity between the lining and the main fabric.

With the right sides facing each other, align the raw edges of the lining and the pile of the main fabric with the batting, respectively.
Sew with ¼" seam allowance along the raw edges. Leave a 2" opening at the middle of the lining side for turning right-side out.

Turn it right side out from the opening, and adjust the cone's tips so that they point out nicely.
Finger press to open the seam and smooth out the piles at the seam allowance, especially if you have an additional batting layer like ours.

Sew to close the opening at the lining.
Push the outer layer into the cone and align both tips, then make a few stitches to secure the position. This step will ensure the lining stays inside the holder.

Lastly, turn the cone-shaped potholder on the right side out to complete the sewing project.

Note – if you substitute a piece of terry towelling for batting, you have made a baby boy “Tee Pee” for protection against those sudden showers….